

Sound	Param	CC#	
BD	Tune	20	
	Attack	21	
	Compress	22	
	Decay	23	
SD	Tune	25	
	Snappy	26	
	Compress	27	
	Decay	28	
LT	Tune	46	
	Decay	47	
MT	Tune	49	
	Decay	50	
HT	Tune	52	
	Decay	53	
RS	Tune	55	
	Decay	56	
HC	Tune	58	
	Decay	59	
CH	Tune	61	
	Decay	62	
OH	Tune	80	
	Decay	81	
CC	Tune	83	
	Decay	86	
RC	Tune	84	
	Decay	87	