


GENERAL GUIDE—FRONT PANEL



- ① OVERALL CONTROL SECTION
- ② MODE SELECT SECTION
- ③ SOLO KEY
- ④ MIDI KEY
- ⑤ PROGRAMMER SECTION
- ⑥ LIQUID CRYSTAL DISPLAY (LCD)
- ⑦ DATA ENTRY SECTION
- ⑧ CARTRIDGE/MIDI KEY
- ⑨ EFFECT SECTION
- ⑩ PARAMETER SECTION
- ⑪ MODULATION WHEEL
- ⑫ PITCH BEND WHEEL
- ⑬ KEYBOARD